

## PPAP Kimball Expectations



## <u>PPAP</u>

Data verification:

Supplier is requested to check the PPAP's data against to:

- Actual supporting documents like Cpk, performance results to be not older than 6 months
- PSW to be filled out correctly (Customer part numer, Customer name, IMDS must be approved firstly) see the example on slide#3
- Obvious Link between Flow, PFMEA, and Control Plan (same step numbers, names, process)
- Highest RPNs/severity addressed (Target RPN<100)
- Historical Quality problems to be obligatory reflected in FMEA and CP
- PSW :supplier name to be given for a Factory not for HQ
- PSW : weight to be given according to AIAG standards



Kimball Electronics Confidential




## <u>PPAP</u>

PPAP contents:

Contents depends of PPAP level, is shall at minimum be:

- Properly filled out PSW -
- IMDS applicable for automotive component




Kimball Electronics Confidential



## <u> PPAP</u>

Supportive documents:

- GSQM <u>keg\_global\_supplier\_quality\_manual</u>
- PPAP AIAG manual 4
- PPAP checklist (document that KE SQ use to check the PPAP)





w

Dokument gramu Microsoft W

> Adobe Acrobat Document



Lasting relationships. Global success.

Kimball Electronics Confidential